

3 In 1 Grill, Sandwich & Waffle Maker



PLEASE READ AND SAVE ALL INSTRUCTIONS TO ENSURE
THE SAFE AND EFFECTIVE USE OF THIS APPLIANCE

Contents

| | |
|----------|------------------------------------------------------------------------|
| Page 3 | Important Safety Instructions |
| Page 4 | General Safety Instructions |
| Page 5 | List of Main Parts, Technical Specifications, Contents of Packaging |
| Page 6-7 | Before First Use, How to Use |
| Page 8 | Recipe Ideas, Maintenance, Service Center |



IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic safety precautions should be observed.

PLEASE READ AND SAVE ALL INSTRUCTIONS BEFORE USING THE 3 IN 1 GRILL, SANDWICH AND WAFFLE MAKER.

1. Close supervision is necessary when any appliance is used near children. The 3 in 1 Grill is not intended for use by children.
2. Do not touch hot surfaces. Use handles, knobs or oven mitts.
3. For indoor household use only.
4. Unplug the 3 in 1 Grill from the outlet when not in use and before cleaning. Allow the 3 in 1 Grill to cool before putting on or taking off parts, and before cleaning.
5. To protect against electric shock, do not immerse cord, plugs, or 3 in 1 Grill base in water or any other liquid.

6. Do not operate the 3 in 1 Grill with a damaged cord or plug, or after the 3 in 1 Grill malfunctions, or has been damaged in any manner. Return the 3 in 1 Grill to the nearest authorized service facility for examination, repair or adjustment.
7. Never use accessories which are not recommended by the manufacturer. They could constitute a danger to the user and risk damage to the 3 in 1 Grill.
8. Never move the 3 in 1 Grill by pulling the cord. DO NOT let the electrical cord hang over the edge of a table or counter or touch hot surfaces.
9. Place the 3 in 1 Grill on a flat, level, stable, heat resistant surface when using.
10. Make sure the cord never comes into contact with the hot parts of the 3 in 1 Grill.
11. Do not place the 3 in 1 Grill on or near a hot gas or electric burner or in a heated oven.

12. Do not use the 3 in 1 Grill with a damaged outlet.
13. Make sure hands are dry when plugging in and unplugging the 3 in 1 Grill.
14. Any examination, repair, or adjustment for the 3 in 1 Grill should be made by the authorized service agent.
15. Do not use this 3 in 1 Grill for other than intended use.
16. Take proper precautions to prevent the risk of burns, fire, or other personal or property damage, as the 3 in 1 Grill generates heat and escaping steam during use.
17. Use only heat resistant wooden or plastic utensils to add or remove food from the 3 in 1 Grill.

SAVE THESE INSTRUCTIONS



If the 3 in 1 Grill should no longer work at all, please make sure that it is disposed of in an environmentally friendly way.

Environmental Protection

STORING
Store the 3 in 1 Grill in a dry location. Do not place any heavy items on top of the 3 in 1 Grill during storage as this may result in possible damage of the 3 in 1 Grill.

1. Remove the sandwich, waffle, or grill plates by pressing and sliding the Upper and Lower Plate Release Buttons.
2. Wash the plates in warm soapy water, rinse, and dry thoroughly before storing.
3. Wipe the base with a damp cloth, sponge, or paper towel. Do NOT immerse the base or run water over the base unit. Dry the surfaces with a soft cloth or paper towel before storing.
4. Do not use abrasive cleaners on the plates or the base unit.
5. To remove cooked on food, use a plastic bristle brush or plastic mesh pad.



Maintenance

CAUTION:
Always be sure that the 3 in 1 Grill is unplugged and completely cooled before cleaning or attempting to store the item. **NEVER IMMERSE** the 3 in 1 Grill base in water or any other liquid.

The 3 in 1 Grill, Sandwich and Waffle Maker is great for heating up and making easy meals and snacks with a variety of your favorite ingredients.

Use your favorite bread or biscuits and fill them with your favorite cheese, meats, peanut butter, pizza sauce or pie filling for an easy lunch or snack.

Make your favorite pancake recipe (or use your favorite mix) and add crispy bacon, blueberries, chocolate chips or your favorite nuts.

Make a delicious Panini sandwich using focaccia or sliced crusty bread and fill it with mozzarella slices, tomato slices, and a few basil leaves or use sliced roast beef, Dijon mustard, caramelized onions and your favorite cheese.

Check your local library or online for more recipes ideas.

Recipe Ideas

To Make Waffles: Insert Waffle Baking Plates



1. Preheat the unit with the lid closed.
2. Open lid and pour approximately $\frac{1}{4}$ cup of waffle batter onto each side of the waffle plate. Do NOT overfill as this could cause a spill and burning of the batter.
3. Close the lid firmly, but do not secure the safety latch.
4. Check your waffle for doneness in approx. 7-8 minutes by gently lifting the lid. If the waffle comes away easily from the lid it should be ready. You may add or delete time depending on your personal taste.
5. Use a wooden kitchen utensil to remove your waffle. Never use a metal utensil as this may cause damage to the non-stick coating.
6. If making more than one waffle, close the lid and let the unit heat up again. When the green Ready Indicator Light goes off you may pour your next waffle.
7. After use, unplug the power supply cord from the outlet and let the unit cool completely before cleaning.



To Grill: Insert Grill Plates

1. Preheat the unit with the lid closed.
2. Place the item to be grilled on the bottom plate and gently close the lid. Do NOT secure the safety latch.
3. When cooking, keep the lid closed. It may be necessary to open the lid briefly to turn the item over for even cooking.
4. When the item reaches your desired doneness, open the lid and remove the item using a wooden kitchen utensil. Never use a metal utensil as this may cause damage to the non-stick coating.
5. If making more than one item, close the lid and let the unit heat up again. When the green Ready Indicator Light goes off you may pour your next item.
6. After use, unplug the power supply cord from the outlet and let the unit cool completely before cleaning.
7. The grill plates are perfect for making paninis and other items that are not high in fat content. NOTE: This item does not have a grease drip container.



General Safety Instructions

WARNING! Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire or serious personal injury. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are a factor which cannot be built into this product, but must be supplied by the operator.

SAVE ALL INSTRUCTIONS!

THIS APPLIANCE HAS A POLARIZED PLUG (ONE PIN IS WIDER THAN THE OTHER) TO REDUCE THE RISK OF ELECTRICAL SHOCK. THIS PLUG IS DESIGNED TO FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY INTO THE OUTLET, TRY THE PLUG THE OTHER WAY AROUND. IF THE PLUG STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. DO NOT ATTEMPT TO ALTER, DISMANTLE OR FIND ANOTHER WAY AROUND THIS SAFETY FEATURE.

CAUTION: A short power supply cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord.

ELECTRIC POWER

If electric circuit is overloaded with other appliances, your 3 in 1 Grill may not operate properly. The 3 in 1 Grill should be operated on a separate electrical circuit from other operating appliances.

SAFETY WARNING

Although your appliance is easy to operate, the warnings below must be followed for your safety:

1. Do not place the appliance near a heat source.
2. Use the appliance on a stable surface.
3. Do not unplug by pulling on the power supply cord.
4. The appliance must be unplugged:
 - A. Before any cleaning or maintenance.
 - B. If it appears to be faulty.

THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY.

SAVE THESE INSTRUCTIONS

Before First Use

- 1. Open lid and remove the pre-installed plates by pressing the Upper and Lower Plate Release Buttons (3, 4).
- 2. Wash plates in warm soapy water, rinse, and dry thoroughly before first use.
- 3. Do NOT immerse base in water or any other liquid.
- 4. To help maintain the non-stick coating, before using the cooking plates for the first time, lightly coat with vegetable oil on a paper towel or lightly spray with a cooking spray. You may do this periodically throughout the use of this product.

How to Use

- 1. Select a matching pair of plates to use depending on what you plan to cook.
- 2. Insert the selected plates securely into the top and bottom of the unit.
- 3. Each set of plates has 2 tabs on the rear edge of the plate. The tabs fit into the rear of the base unit.
- 4. Each set of plates has a metal tab in the center of the front edge of the plate. This will snap into the center locking tab on the top and bottom of this unit. Press plates firmly into place to secure the plate into the proper position.
- 5. Close the lid and plug the power supply cord into a standard 120V outlet. Both indicator lights will come on.
- 6. Always preheat the unit with the lid closed. The green Ready Indicator Light will turn off when the unit is preheated, approx. 3-5 minutes. PLEASE NOTE: the green Ready Indicator Light will cycle on and off throughout the cooking time to let you know that the unit has reached its maximum temperature. It does NOT indicate when the cooking time is complete.


To Make Pocket Sandwiches: Insert Sandwich Making Plates



- 1. Prepare your sandwich using 2 slices of bread and your choice of fillings. DO NOT overfill your sandwich as this could cause a spill and prevent the safety latch from closing completely. For best results leave a minimum of a 1/2" edge around the filling.
- 2. You may lightly butter the side of the bread that will come into contact with the heated sandwich making plates to obtain a golden brown.
- 3. Once the unit is preheated, carefully open the unit and place the sandwich on the bottom plate. Gently, but firmly close the lid and secure the safety latch. Please note you may see a little bit of steam escaping from the unit. This is normal.
- 4. Unlock the safety latch and check the sandwich in 4-5 minutes to see if it is golden brown. You may add or delete time depending on your personal taste.
- 5. Use a wooden kitchen utensil to remove your sandwich. Never use a metal utensil as this may cause damage to the non-stick coating.
- 6. If making more than one sandwich, close the lid and let the unit heat up again. When the green Ready Indicator Light goes off you may add your next sandwich.
- 7. After use, unplug the power supply cord from the outlet and let the unit cool completely before cleaning.

List of Main Parts

- 1. Safety Latch
- 2. Sandwich Making Plates
- 3. Lower Plate Release Button
- 4. Upper Plate Release Button
- 5. Power Indicator Light
- 6. Ready Indicator Light
- 7. Power Supply Cord
- 8. Carry Handle
- 9. Waffle Baking Plates
- 10. Grill Plates



Technical Specifications

| | | | |
|----------------|-------------|---------------|------|
| Model Number | 80-SM15 | Rated Wattage | 750W |
| Rating Voltage | 120VAC 60Hz | | |

Contents of Packaging

- a. Base
- b. 2 Grill Plates
- c. 2 Sandwich Making Plates
- d. 2 Waffle Baking Plates
- e. Instruction Manual